

# 8 and 11 Blade SPA Cutting Units Greensmaster® 3000 Series Traction Units

Model No. 04450—220000001 and Up Model No. 04468—220000001 and Up

## **Parts Catalog**

### **Ordering Replacement Parts**

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

### **Understanding Reference Numbers**

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

#### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

#### **Reference Numbers Indicating Quantity**

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.




T-3809

## **Reel and Frame Assembly**

Ref. No.	Part No.	Qty.	Description
5	302–11	2	Fitting-Lube, 45°
8	3256–22	4	Washer-Flat
9	3296–42	2	Nut-Lock, NI
10	57-5200	1	Grass Shield ASM
10:5	3295–46	13	Rivet
10:6	57-5210	1	Shield Flap
11	104-2065	5	Screw-HWH
13	36-7260	1	Bar–Off, Cut
15	70–1200–01	1	Frame-Reel
18	12-0460	1	Caplug
22	3256–14	5	Washer-Flat
24	321–5	2	Screw-HH
25	77–1080	1	Adjust–HOC, LH
26	52-3110	1	Bolt-HOC Shoulder,
			RH
34	77–0490	1	Decal-Bolt, Eccentric
40	32128–36	2	Nut–HF
41	57–9910	2 2 2	Pivot Screw
42		2	Washer-Lock, Internal
45	104–3399		Bearing Housing ASM
45:2		1	Seal-Grease
45:3	254–72	1	Bearing-Cup, Tapered
46		2	Bearing W/Grease
46:1		1	Bearing-Cone, Taper
47	1	1	Nut-Lock, NI
48	323–2	1	Screw-HH


Ref. No.	Part No.	Qty.	Description
49		1	End Cap ASM
49:1	10-5080-01	1	Cap–End
49:2	253-61	1	Seal–Oil
50	57-3210	4	Screw
51	3255–9	4	Washer-Lock/Ext
55	52–3100	1	Bolt-HOC Eccentric, LH
58	77–1060	1	Adjust-HOC, RH
59	3256-24	4	Washer-Flat
60	3296-39	6	Nut-Lock, NI
61	3246-2	2	Setscrew-HSH
63	237-84	2	Grommet
64	52-3120	1	Roller ASM
64:1	21-6430	2	Bearing
64:2	302–5	2	Fitting-Grease
67	12–3599	1	8 Blade Reel ASM
67	12–2789	1	(only on: 04468) 11 Blade Reel ASM (only on: 04450)
70	93-1394	1	Nut-Spline
71	323-7	2	Screw-HH



## **Bed Bar Assembly**

Ref. No.	Part No.	Qty.	Description
1	52-2930	1	Bolt-Shoulder
2	3220-6	2	Nut-Jam
3	52-2860	1	Washer
4		2	Washer
5	66-7240	2	Screw-Pivot
6	52-2890	4	Bushing-Nylon
7	77-0330	1	Housing-Pivot
8	77-0350	2	Washer-Thrust, Nylon
10	257-5	1	Washer-Thrust
11	66-7220	1	Arm-Spring
12	77-0300-01	1	Handle ASM
13	62-5510	2	Bushing-Rubber
14	324-25	1	Screw_HH
	3256-25	1	Washer-Flat
16	302-18	1	Fitting-Grease
17	57-5260	1	Pivot–Bedbar
20		1	Bedbar/Bushing ASM
20:1	63-9510	2	Bushing
20:2	57-4910	13	Screw
21	57-4940-01	1	Bedbar
22	93-4262	1	Bedknife-Microcut
22	93-4263	1	Bedknife-Tournament
22	93-4264	1	Bedknife-Lowcut
22	94-6392	1	Bedknife-Highcut
23	65–8600	2	Knob–Adjustment, Height

Ref. No.	Part No.	Qty.	Description
24 25 26 27 33 34 35 36 37 40 41 42 43 45	10–5060 3256–23 3296–29 10–5010 94–2958 3254–6 3253–3 321–4 32108–20 3–7253 3255–8	1 2 2 2 2 2 2 2 2 2 1 1	Bolt–Eccentric Bracket–HOC Washer–Flat Nut–Lock, NI Screw–Adjustment, Roller Stud–Ball Washer–Lock, Internal Washer–Lock Screw–HH Screw Bolt–Carriage Washer–Lock/Ext Screw–HH Spring–Compression



Ref. No.	Part No.	Qty.	Description
1:3 2 2:2 2:3 3:3 3:2 3:3 5 5:2 5:3 7 8 8:2	302–5 52–3180 88–6790 302–5 52–3180 33–1000 11–0070 8–2530 3295–2 3254–8	1 2 2 1 2 2 1 2 2 1 1 1 1 4 4 4	Bearing-Roller, Front Fitting-Grease Wiehle Roller ASM Fitting-Grease Bearing-Roller, Front Wiehle Roller ASM Fitting-Grease Bearing-Roller, Front Scraper Brush ASM Scraper Comb ASM Comb Rivet-Semi

Ref. No.	Part No.	Qty.	Description